


# Full-Mold, Separate Excitation Switching Type

#### **■**Features

- Compact full-mold package (equivalent to TO220)
- Output current: 3.0A
- High efficiency: 79 to 91%
- Requires only 4 external components
- · Phase correction and output voltage adjustment performed internally
- Built-in reference oscillator (60kHz)
- Built-in overcurrent and thermal protection circuits
- Built-in soft start circuit (output ON/OFF control)

#### ■Applications

- Power supplies for telecommunication equipment
- Onboard local power supplies



## ■Lineup

Part Number	SI-8033S	SI-8050S	SI-8090S	SI-8120S	SI-8150S	
Vo(V)	3.3	5.0	9.0	12.0	15.0	
Io(A)			3.0		•	

## **■**Absolute Maximum Ratings

Parameter	Symbol	Unit	
DC Input Voltage	Vin	43 <sup>*</sup>	V
Power Dissipation	P <sub>D1</sub>	18(With infinite heatsink)	W
Fower Dissipation	P <sub>D2</sub>	1.5(Without heatsink, stand-alone operation)	W
Junction Temperature	Tj	+125	°C
Storage Temperature	Tstg	-40 to +125	°C
SW Terminal Applied Reverse Voltage	Vsw	-1	V
Thermal Resistance(junction to case)	Rth(j-c)	5.5	°C/W

<sup>\*</sup>SI-8033S: 35V

## **■**Recommended Operating Conditions


Parameter	Symbol			Unit			
i didilletei	Symbol	SI-8033S	SI-8050S	SI-8090S	SI-8120S	SI-8150S	Offic
DC Input Voltage Range	Vin	5.5 to 28 7 to 40		12 to 40	2 to 40 15 to 40		V
Output Current Range	lo			A			
Operating Junction Temperature Range	Tjop			°C			

## **■**Electrical Characteristics


(Ta=25°C)

								F	Ratings	S										
Parameter	Symbol	SI-8033S		SI-8050S			SI-8090S			SI-8120S			SI-8150S			Unit				
		min.	typ.	max.	min.	typ.	max.	min.	typ.	max.	min.	typ.	max.	min.	typ.	max.				
SI-8000S *1	Vo	3.17	3.30	3.43	4.80	5.00	5.20	8.55	9.00	9.45	11.50	12.00	12.50	14.25	15.00	15.75				
Output Voltage SI-8000SS	VO	3.234	3.30	3.366	4.90	5.00	5.10	8.73	9.00	9.27			•				V			
	Conditions	Vin=	15V, lo=	1.0A	Vin=20V, Io=1.0A Vin=21V, Io=1.0A Vi			Vin=	VIN=24V, Io=1.0A			Vin=25V, Io=1.0A								
Efficiency	η		79			84			88			90			91		%			
Liliciency	Conditions	Vin=	15V, lo=	1.0A	Vin=	20V, Io=	1.0A	Vin=	21V, Io=	1.0A	Vin=	24V, lo=	1.0A	Vin=	25V, lo=	1.0A	70			
Switching Frequency	f		60			60			60			60			60		kHz			
Switching Frequency	Conditions	Vin=	15V, lo=	1.0A	Vin=	20V, lo=	1.0A	Vin=	21V, Io=	1.0A	VIN=24V, Io=1.0A VIN=25V, Io=1.0A		1.0A	] KITZ						
Line Regulation	ΔVOLINE		25	80		40	100		50	120		60	130		60	130	mV			
Line Regulation	Conditions	Vin=8	to 28V, Id	=1.0A	Vin=10 to 30V, Io=1.0A		VIN=15 to 30V, Io=1.0A		Vin=18 to 30V, Io=1.0A			Vin=21 to 30V, Io=1.0A		] ''''						
Load Regulation	$\Delta V$ oload		10	30		10	40		10	40		10	40		10	40	mV			
Load Regulation	Conditions	VIN=15	V, lo=0.5	to 1.5A	VIN=20V, Io=0.5 to 1.5A		VIN=21V, Io=0.5 to 1.5A		VIN=24V, Io=0.5 to 1.5A			Vin=25V, Io=0.5 to 1.5A		''''						
Temperature Coefficient of Output Voltage	ΔVo/ΔTa		±0.5			±0.5			±1.0			±1.0			±1.0		mV/°C			
Ripple Rejection	Rrej		45			45			-45			45			45		dB			
Ripple Rejection	Conditions	f=1	00 to 12	0Hz	f=100 to 120Hz		f=100 to 120Hz		f=100 to 120Hz			f=100 to 120Hz			l ub					
Overcurrent Protection	ls <sub>1</sub>	3.1			3.1			3.1			3.1			3.1			A			
Starting Current	Conditions		VIN=15V	1	VIN=20		1	VIN=21V		/	VIN=24V		Vin=25V		A					


<sup>\*1: &</sup>quot;S" may be indicated to the right of the Sanken logo.




## **■**Block Diagram



## **■**Standard External Circuit



## ■Ta-PD Characteristics




$$P_D = V_O \bullet I_O \left( \frac{100}{\eta \chi} - 1 \right) - V_F \bullet I_O \left( 1 - \frac{V_O}{V_{IN}} \right)$$


The efficiency depends on the input voltage and the output current. Thus, obtain the value from the efficiency graph on page 83 and substitute the percentage in the formula above.


Vo : Output voltage
V<sub>IN</sub> : Input voltage
Io : Output current
ηx : Efficiency (%)
VF : Diode forward voltage
0.5V(RK46)

Thermal design for D<sub>1</sub> must be considered separately.

## ■Typical Characteristics










## Temperature Characteristics(SI-8050S)

## Overcurrent Protection Characteristics(SI-8050S)

#### Thermal Protection Characteristics(SI-8050S)










#### **Note on Thermal Protection:**

The thermal protection circuit is intended for protection against heat during instantaneous short-circuiting. Its operation is not guaranteed for short-circuiting over extended periods of time.







## **Caution**

## 1. Selecting External Components

(1) Choke coil L<sub>1</sub>

To maintain the stable operation of the regulator, choke coil L<sub>1</sub> should be selected appropriately.

When selecting choke coil L<sub>1</sub>, consider the following:

 a) Suitable for a switching regulator
 Do not use a coil as a noise filter because it generates excess heat.

#### b) Appropriate inductance

The greater the inductance of the choke coil, the smaller the output ripple voltage. However, the size of the coil increases large as the inductance increases. If the inductance is low, a greater peak current flows to the IC and loss increases. This is not favorable for stable operation.

The standard external circuit shows reference inductance values suitable for stable operation. However, the appropriate inductance may also be calculated as follows:

$$L = \frac{(V_{IN} - V_O) \cdot V_O}{\Delta I L \cdot V_{IN} \cdot f}$$

Where, deltalL indicates the ripple current of the choke coil that is roughly set as follows:

 If the working output current is close to the maximum rating (3 A) of SI-8000S

Ripple current = output current  $\times$  0.2 to 0.3


• If the working output current is about 1.0A or less Ripple current = output current × 0.3 to 0.4

#### c) Satisfying the rated current

The rated current of a choke coil must be greater than the maximum load current. Note that the inductance decreases drastically and an excess current flows if the load current exceeds the rated current of the coil.

#### d) Good DC current superposition characteristics

The current flowing through a choke coil is a triangular waveform current superimposed on a DC current equal to the load current. The coil inductance decreases as the load current increases. In general, the coil can be used until the inductance drops to 50% of the rated value. Use this as the reference value for selection.



#### e) Less noise

A drum-type open magnetic core coil can affect peripheral circuits with noise because the flux passes outside the coil. To avoid this problem, use a toroidal, EI, or EE type open magnetic core coil.

#### (2) Input capacitor C1

Input capacitor C<sub>1</sub> operates as a bypass capacitor in the input circuit.

When selecting input capacitor C1, consider the following:

- a) The breakdown voltage is higher than the maximum input voltage.
- b) Satisfies the allowable ripple current

Exceeding the ratings of this capacitor or using it without derating may reduce its service life and also cause the regulator to malfunction. Therefore, an input capacitor with a sufficient margin should be selected. With the SI-8000S Series, the effective ripple current Irms flowing to the input capacitor can be calculated approximately as follows:

$$I_{rms} = 1.2 \times \frac{Vo}{V_{IN}} \times Io$$

#### (3) Output capacitor C2

Output capacitor C2 operates as a smoothing capacitor for switching output. The output ripple voltage from the regulator is determined by the product of the pulsating current part  $\Delta IL$  (=C2 charge-discharge current) of the choke coil current and the equivalent series resistance ESR of the output capacitor C2.

Therefore, a capacitor of low equivalent series resistance ESR should be selected to reduce the output ripple voltage. It is recommended to select a low-impedance capacitor intended for use with switching regulators as C<sub>2</sub>.


#### (4) Diode D<sub>1</sub>

Use a Schottky barrier diode for D<sub>1</sub>. If you use a general rectifier diode or fast recovery diode, the IC may be damaged. (Sanken RK46 recommended)

#### 2. Notes on Pattern Design


#### (1) Large current line


Since a large current flows through the bold lines in the standard external circuit make the pattern as wide and as short as possible.



## (2) Input capacitor

Place the input capacitor  $C_1$  and output capacitor  $C_2$  as close to the IC as possible. Since a large current flows through the lead wires of the input and output capacitors to charge and discharge them quickly, minimize the lead wire length. The pattern around the capacitors should also be minimized.






Example of bad pattern

Example of good pattern

#### (3) Sensing terminal

Output voltage sensing terminal Vos should be connected as close to output capacitor C<sub>2</sub> as possible. If the terminal is far from the capacitor, the decreasing regulation and increasing switching ripple may result in abnormal oscillation.

Example of basic pattern



Top view (with part names)

# **Applications**

#### 1. Soft Start

Connecting a capacitor to terminal no. 5 permits a soft start at power-on. Delay time  $T_{\rm d}$  and rise time  $T_{\rm s}$  can roughly be calculated as shown below. (However, the values may slightly vary in an actual application.) If the capacitance of  $C_3$  is increased, it takes longer to discharge  $C_3$  after  $V_{IN}$  is turned off. Therefore, it is recommended to set the value within  $10\mu F.$  When not using the soft start function, keep terminal no. 5 open.

$$T_{d} = \frac{0.7 \times C_{3}}{20 \times 10^{-6}} \text{ (sec)}$$

$$T_{s} = \frac{4.845 \times C_{3}}{V_{IN} \times 20 \times 10^{-6}} \text{ (sec)}$$

$$SI-8000S$$

$$5$$

$$S.S.$$


$$C_{3}$$

$$V_{0}$$

$$V_{IN}$$

#### 2. Output ON/OFF control


Output can be turned on and off by using the soft start terminals. Set the soft start terminal voltage to VssL (0.2V typ.) or less to stop output. To switch the potential at the soft start terminals, drive the open collector of the transistor. Since the discharge current from  $C_3$  flows to the ON/OFF control transistor, limit the current for protection. The SS terminal is pulled up to the power supply in the IC and no external voltage can be applied.



#### 3. Variable Output Voltage

The output voltage can be increased by connecting a resistor to Vos terminal No. 4. (There is no way of decreasing the voltage)

(1) Variable output voltage with single external resistor



The output voltage adjustment resistance Rex is calculated as follows:


$$Rex = \frac{Vo' - Vs}{IVs}$$

Vs : Set output voltage of product Vo' : Adjusted output voltage Ivs : Inflow current to Vs terminal

 $^{\star}$  The temperature characteristics of output voltage worsen because the value Rex is not compensated for temperature. The Vs value fluctuates by up to  $\pm 20\%$  depending on the IC product. Since the output voltage fluctuates more, a semi-fixed resistor is necessary for accurate output voltage adjustment. If Vs and Rex are constant, the range of output voltage fluctuation can be expressed as follows:

ΔVo':Adjusted output voltage

(2) Variable output voltage with two external resistors



The output voltage adjustment resistances Rex1 and Rex2 are calculated as follows:

$$Rex1 = \frac{Vo'-Vs}{S \cdot IVs}$$

$$Rex2 = \frac{Vs}{(S-1) \cdot IVs}$$
S:Stability factor

Bypassing the current to Rex2 improves the temperature characteristics and voltage fluctuation ranges more than the method of (1). Stability factor S indicates the ratio of Rex1 to Vs terminal inflow current. Increasing the S value improves the fluctuations of the temperature characteristics and output voltage. (Usually 5 to 10)

If the Vs and Rex values are constant, the output voltage fluctuation range can be calculated as follows:

$$\Delta Vo'(\%) = \frac{\pm 20}{S} \bullet \frac{Vo' - Vs}{Vo'}$$