



## Silicon Switching Diode Array

BAV 99

### Features

- For high-speed switching
- Connected in series



Type	Marking	Ordering Code (tape and reel)	Pin Configuration	Package <sup>1)</sup>
BAV 99	A7s	Q68000-A549		SOT-23

### Maximum Ratings per Diode

Parameter	Symbol	Values	Unit
Reverse voltage	$V_R$	70	V
Peak reverse voltage	$V_{RM}$	70	
Forward current	$I_F$	200	mA
Surge forward current, $t = 1 \mu\text{s}$	$I_{FS}$	4.5	A
Total power dissipation, $T_S = 31^\circ\text{C}$	$P_{tot}$	330	mW
Junction temperature	$T_J$	150	$^\circ\text{C}$
Storage temperature range	$T_{stg}$	- 65 ... + 150	

<sup>1)</sup>For detailed information see chapter Package Outlines.

**Thermal Resistance**

Junction - ambient <sup>2)</sup>	$R_{th\ JA}$	$\leq 500$	K/W
Junction - soldering point	$R_{th\ JS}$	$\leq 360$	

**Electrical Characteristics per Diode**at  $T_A = 25^\circ\text{C}$ , unless otherwise specified.

Parameter	Symbol	Values			Unit
		min.	typ.	max.	

**DC characteristics**


Breakdown voltage $I_{(BR)} = 100 \mu\text{A}$	$V_{(\text{BR})}$	70	—	—	V
Forward voltage $I_F = 1 \text{ mA}$	$V_F$	—	—	715	mV
$I_F = 10 \text{ mA}$		—	—	855	
$I_F = 50 \text{ mA}$		—	—	1000	
$I_F = 150 \text{ mA}$		—	—	1250	
Reverse current $V_R = 70 \text{ V}$ $V_R = 25 \text{ V}, T_A = 150^\circ\text{C}$ $V_R = 70 \text{ V}, T_A = 150^\circ\text{C}$	$I_R$	—	—	2.5	$\mu\text{A}$
		—	—	30	
		—	—	50	

**AC characteristics**

Diode capacitance $V_R = 0 \text{ V}, f = 1 \text{ MHz}$	$C_D$	—	—	1.5	pF
Reverse recovery time $I_F = 10 \text{ mA}, I_R = 10 \text{ mA}, R_L = 100 \Omega$ measured at $I_R = 1 \text{ mA}$	$t_{rr}$	—	—	6	ns

<sup>2)</sup>Package mounted on epoxy pcb 40 mm × 40 mm × 1.5 mm/6 cm<sup>2</sup> Cu.

### Test Circuit for Reverse Recovery Time




Pulse generator:  $t_p = 100 \text{ ns}$ ,  $D = 0.05$   
 $t_r = 0.6 \text{ ns}$ ,  $R_j = 50 \Omega$

Oscillograph:  $R = 50 \Omega$   
 $t_r = 0.35 \text{ ns}$   
 $C \leq 1 \text{ pF}$


### Forward current $I_F = f(T_A^*; T_S)$



\* Package mounted on epoxy



### Forward current $I_F = f(V_F)$

$T_A = 25 \text{ }^\circ\text{C}$



**Reverse current**  $I_R = f(T_A)$ **Forward voltage**  $V_F = f(T_A)$ **Peak forward current**  $I_{FM} = f(t)$  $T_A = 25^\circ\text{C}$ 